



```

arch/arm/cpu/armv7/start.S
  reset, 40
    1 → cpu_init_cp15, 139
    2 → cpu_init_crit, 311
  
```

```

arch/arm/cpu/armv7/low_level_init.S
  low_level_init, 25
  
```

```

arch/arm/cpu/armv7/mx6/soc.c
  s_init, 580
  
```

```

arch/arm/lib/crt0.S
  _main, 67
  
```

```

common/init/board_init.c
  board_init_f_alloc_reserve, 67
  board_init_f_init_reserve, 100
  
```

```

common/board_f.c
  board_init_f, 908
  setup_mon_len, 222
  
```

```

lib/initcall.c
  initcall_run_list, 3
  
```

```

arch/arm/lib/relocate.S
  relocate_code, 81
  relocate_vectors, 44
  
```

```

arch/arm/cpu/armv7/start.S
  c_runtime_cpu_setup, 97
  
```

```

arch/arm/lib/memset.S
  memset, 24
  
```

```

common/board_r.c, 904
  board_init_r, 24
  
```

```

lib/initcall.c
  initcall_run_list, 3
  
```

```

common/board_r.c
  initr_trace, 101
  initr_reloc, 106
  initr_caches, 119
  initr_reloc_global_data, 132
  initr_malloc, 264
  initr_bootstage, 264
  
```

```

include/bootstage.h
  bootstage_relocate, 377
  
```

```

common/board_r.c
  initr_dm, 308
  
```

```

drivers/core/root.c
  dm_init_and_scan, 323
  
```

```

board/freescale/wirelessroad_ecspi3/wirelessroad_ecspi3.c
  board_init, 597
  
```

```

lib/efi_loader/efi_memory.c
  efi_memory_init, 456
  
```

```

common/stdio.c
  stdio_init_tables, 316
  
```

```

common/board_r.c
  initr_serial, 178
  initr_nand, 424
  initr_mmc, 444
  initr_env, 484
  cpu_secondary_cpu, 89
  
```

```

common/stdio.c
  stdio_add_devices, 347
  
```

```

common/board_r.c
  initr_jumptable, 512
  
```

```

common/cli.c
  cli_loop, 218
  
```

```

common/autoboot.c
  _abortboot, 236
  
```

```

common/main.c
  main_loop, 48
  
```

```

common/board_r.c
  run_main_loop, 692
  initr_net, 602
  
```

```

board/freescale/wirelessroad_ecspi3/wirelessroad_ecspi3.c
  board_late_init, 659
  
```

```

common/board_r.c
  initr_ethaddr, 537
  initr_enable_interrupts, 529
  
```

```

arch/arm/lib/interrupts.c
  interrupt_init, 34
  
```

```

common/console.c
  console_init_r, 839
  
```

```

board/freescale/wirelessroad_ecspi3/wirelessroad_ecspi3.c
  dram_init, 173
  
```

```

common/board_f.c
  setup_reloc, 634
  reloc_fdt, 603
  show_dram_config, 161
  dram_init_banksize, 183
  reserve_stacks, 516
  reserve_fdt, 481
  reserve_global_data, 466
  reserve_board, 446
  reserve_malloc, 437
  reserve_uboot, 413
  reserve_mmu, 347
  reserve_round_4k, 338
  setup_des_addr, 288
  
```

```

common/board_f.c
  announce_dram_init, 148
  init_func_i2c, 193
  
```

```

common/board_info.c
  show_board_info, 24
  
```

```

arch/arm/imx-common/cpu.c
  print_cpuinfo, 188
  
```

```

common/board_f.c
  display_text_info, 125
  
```

```

lib/display_options.c
  display_options, 16
  
```

```

common/console.c
  console_init_f, 703
  
```

```

lib/fdtdec.c
  fdtdec_setup, 1211
  fdtdec_prepare_fdc, 599
  
```

```

common/dlmalloc.c
  initf_malloc, 2376
  
```

```

common/board_f.c
  init_bootstage, 703
  init_console_record, 728
  
```

```

arch/arm/cpu/armv7/mx6/soc.c
  arch_cpu_init, 359
  
```

```

common/board_f.c
  initf_dm, 737
  
```

```

board/freescale/wirelessroad_ecspi3/wirelessroad_ecspi3.c
  board_early_init_f, 587
  
```

```

arch/arm/imx-common/speed.c
  get_clocks, 19
  
```

```

arch/arm/cpu/armv7/mx6/soc.c
  board_postclk_init, 504
  
```

```

common/env_sf.c
  env_init, 337
  
```

```

common/board_f.c
  init_baud_rate, 119
  
```

```

drivers/serial/serial.c
  serial_init, 411
  
```